

4.) REMOVE PIPE UP TO AND INCLUDING THE VERTICAL 90 AND PLACE TAPPED CAP ON END OF PIPE.

5.) REMOVE PLUG AND CONNECT REUSE MAIN TO EXISTING GV.

2.) PLACE TAPPED CAP ON END OF PIPE.

6.) GROUT PIPE BETWEEN CAPS WITH FLOWABLE FILL OR REMOVE PIPE COMPLETELY.

3.) REMOVE RPZ BFP AND CAP ABOVE GROUND TEE W/ BLIND FLANGE

SEE DETAIL TOHO-22
(ABOVE GROUND PIPING SHALL BE REPAINTED PANTONE PURPLE)

1.) CLOSE AND PLUG GV. REMOVE PIPE FROM VALVE AND ALL FITTINGS DOWNSTREAM OF VALVE.

REUSE WATER MAIN

POTABLE WATER MAIN

FLOW



EFFECTIVE DATE:	04/01/2025
BOARD APPROVED DATE:	01/22/2025
PREVIOUS VERSION:	NA
DRAWN BY:	DT
REVISED BY:	DT

POTABLE TO REUSE JUMPER REMOVAL

DRAWING NUMBER

22.2