



NOTES:

1. #57 STONE BEDDING SHALL BE REQUIRED A MINIMUM DEPTH OF 6" BELOW ALL VALVES. PLACE FILTER FABRIC OVER STONE PRIOR TO SETTING VALVE
2. MAINTAIN A MINIMUM HORIZONTAL SEPARATION OF 3' FROM ALL PLANTINGS, STRUCTURES, OTHER UTILITY FIXTURES, ETC. AROUND ALL VALVES
3. OPERATING NUT SHALL BE BOLTED, SHEER PINS ARE NOT PERMITTED
4. WHERE THE OPERATING NUT CANNOT BE SET AT A MAXIMUM DEPTH OF 18", A BOLT ON VALVE NUT RISER SHALL BE REQUIRED
5. FULL DEPTH CAST IRON SCREW TYPE ADJUSTABLE VALVE BOXES ARE REQUIRED. PVC OR DIP EXTENSIONS/RISERS SHALL NOT BE PERMITTED
6. LOCATOR WIRE ACCESS FOR DIRECTIONAL BORE OR JACK AND BORE APPLICATIONS:
 - 6.1. IN UNPAVED AREAS USE 2" SCH80 PVC, FEMALE ADAPTER COUPLING AND 2" BRASS PLUG W/ RECESSED NUT SET IN THE VALVE PAD
 - 6.2. IN PAVED AREAS TERMINATE THE LOCATE WIRE INSIDE THE TOP PORTION OF THE VALVE BOX
 - 6.3. PROVIDE A MINIMUM OF 12" OF EXTRA WIRE ABOVE FINISHED GRADE
7. PRIVATELY MAINTAINED WATER SYSTEMS SHALL HAVE 'PRIVATE' STAMPED ON THE BRONZE DISC
8. DEDICATED FIRE LINES SHALL HAVE 'FIRE' STAMPED ON THE BRONZE DISC AND THE VALVE COVER SHALL BE PAINTED RED